

## Instruction Manual LEWI INDOOR-System




Fill the bottle with de-mineralised water.



Connect the bottle top to the control unit. (Blue connection)



Connect the hose from the telescopic pole to the control unit (Gold coloured connection)




Then connect the electric plug of the telescopic pole to the control unit (silver coloured connection).



Attach the Microfiber pad to the pad holder.



Keep the red push button pressed down until water runs out of the top end of the hose (see next picture).



Only then connect the hose to the nozzles. Now you can start cleaning.



Connect charger to control unit. Unit is fully charged when LED on charger changes from red to green.

Charge level indicator:  
Please charge system when the light is red.