


# QLEEN



PURE WATER CLEANING SYSTEMS

## Quick Guide PROFI II








### 1. Connection water and power


- 1.1 The **water input** (Fig. 1) can be connected as follows:
  - With the Gardena adapter via a Gardena hose to the house water connection and
  - Then open the water inlet of the house water connection
  - Remove the Gardena adapter and connect the suction hose to the machine and sink the side with the filter into the water tank
- 1.2 Connect the **mains plug** (Fig. 1) supply to the power socket
- 1.3 Unroll the hose to the required length and connect the **connection for the black hose** (Fig. 1) to the reel
- 1.4 Switch on the machine with  button lights **green** for battery operation and **turquoise** for mains operation.
- 1.5 If the **battery indicator** (Fig. 5) shows **red** and the machine does not start, the battery must be charged, see Chapter 9. **Charging the battery**






### 2. Bleeding

- 2.1 Open the **bleeding tap** (Fig. 1)
- 2.2 Switch on with the key  (off ⇒ **green**) and wait until water comes evenly from the vent hose under the machine
- 2.3 Switch on with the key  (**green** ⇒ off)
- 2.4 Place the **suction hose for the cleaning solution** (Fig. 1) into the cleaning solution tank
- 2.5 Set the **dosing pump regulator** (Fig. 2) to 100%
- 2.6 Switch on with the key  (off ⇒ **green/turquoise**) and wait until the key  lights up **green** continuously
- 2.7 Switch off with the key  (**green** ⇒ off)
- 2.8 Attach the hose to the rod and brush bow or ROTAQLEEN, connect cable for the ROTAQLEEN to the **ROTAQLEEN socket** (Fig. 1) and the ROTAQLEEN.
- 2.9 The machine is ready for operation

### 3. Cleaning with pure water





- 3.1 Switch on the machine with the key  (off ⇒ **green**)
- 3.2 After a short time, the clean water arrives at the nozzles via the blue hose

### 4. Cleaning with cleaning solution



- 4.1 Switch on the machine with the key  (off ⇒ **green**), if the key  should light up **turquoise** the **dosing pump controller** (Fig. 2) is set to 0 % and must be turned up  (**turquoise** ⇒ **green**)
- 4.2 After a short time, the cleaning agent solution arrives at the nozzles via the black hose

- 4.1 The dosing quantity is adjusted with the **dosing pump regulator (Fig. 2)**
- 4.2 The total amount of the cleaning solution can be adjusted with the **water flow regulator (Fig. 1)**, if the total amount is decreased, the concentration of the solution is increased

## 5. Cleaning with tap water

- 5.1 Press the button  (off / green ⇒ turquoise) for 2 seconds, only tap water comes through the blue hose
- 5.2 To switch to pure water, press the key  (off / turquoise ⇒ green) again for 2 seconds
- 5.3 Press the key  (off / green ⇒ turquoise) for 2 seconds, the dosing pump is switched off and only tap water comes through the black hose
- 5.4 To switch on the dosing pump again, press the key  (off / turquoise ⇒ green) for 2 seconds


## 6. Control of the ROTAQLEEN

- 6.1 The ROTAQLEEN starts automatically in forward operation or last selected direction, if pure/line water and/or cleaning solution/line water is switched on
- 6.2 For a change of direction of the ROTAQLEEN press the key  (green ⇒ turquoise) and for back  (turquoise ⇒ green)





**Note: The machine can be controlled in parallel with the remote control in the same way**

## 7. Water quality meter and water clock


- 7.3 The **water quality meter (Fig. 3)** shows the temperature and the quality of the pure/line water for the blue hose.
- 7.4 We recommend changing the granules at a value of 50 µS
- 7.5 The **water clock (Fig.3)** measures the quantity of pure water produced



## 8. After cleaning

- 8.1 Switch off the machine with the  (green / turquoise ⇒ off) and/or  (green / turquoise ⇒ off) key
- 8.2 Cleaning solution was used:
  - Place the **suction hose for cleaning solution (Fig. 1)** in tap water
  - Set the **dosing pump regulator (Fig. 2)** to 100%
  - Switch on with the key  (off ⇒ green) and rinse the dosing pump for 2 min
  - Then switch off the machine with the key  (green ⇒ off)
- 8.3 Pull out the mains plug (optional), close the water supply and disconnect the connection
- 8.4 Remove the **connection for the black hose (Fig. 1)**, roll up the hose

## 9. Battery charging

- 9.1 Connect the **mains plug (Fig. 1)** to the power socket
- 9.2 The machine must be switched off or running in optional mains operation for charging  (off or turquoise)
- 9.3 The **charging indicator (Fig. 5)** lights up **red** after a short time, changes in the loading process to **yellow** and then **green** ⇒ the charging of the battery is completed

**Karlhans Lehmann KG, Kranichstraße 2a, DE -17235 Neustrelitz**

Homepage: [www.qleen.de](http://www.qleen.de)  
 Phone: +49 (0)3981 48850  
 E-Mail: [info@qleen.de](mailto:info@qleen.de)